Downloaded from www.vandenborre.be

Destinator User Manual

Downloaded from www.vandenborre.be

Copyright

1. Limited Product Warranty Destinator Technologies, warrants to the Client that the Products shall substantially conform to Destinator Technologies' specification for a period of one (1) year from the date of the original purchase by the end user (the "Warranty Period"). As Destinator Technologies' sole obligation and Client's exclusive remedy for any breach of warranty, Destinator Technologies agrees, at its sole option, to (i) use reasonable efforts to repair the Product with new or refurbished replacement parts; (ii) replace the Product with a new or refurbished unit; or (iii) refund the purchase price, provided Client returns the defective Products to Destinator Technologies with proof of purchase and Destinator Technologies' authorization.

Destinator Technologies' warranty hereunder does not apply in case of any damage caused by accident, abuse, misuse, misapplication or alteration of any kind performed by anyone other than Destinator Technologies. The Products are not designed or licensed for use in mission-critical applications, or in hazardous environments, requiring fail-safe controls, including without limitation operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, or life support or weapons systems. Without limiting the generality of the foregoing, Destinator Technologies specifically disclaims any express or implied warranty or condition of fitness for such purposes. Destinator Technologies' warranty does not, in any event, apply to physical damage to the surface of the Product or replacement. Destinator Technologies shall have no obligation with respect to any data stored in the Product.

Except as expressly stated in this section, Destinator Technologies makes no warranties or includes any conditions with respect to the products, express or implied, including, but not limited to, the implied warranties or conditions of merchantability, fitness for a particular purpose and no infringement.

2. Liability Limitation. In no event shall Destinator Technologies, be liable to Client, (and Client hereby waives any indirect, special, incidental, or consequential damages in connection with) for the transactions contemplated by this agreement, whether or not such damages were foreseen or their likelihood disclosed. Destinator Technologies shall not be liable to Client or any third party claiming through Client, for any damages of any kind in excess of the amounts paid by Client under the terms of this agreement with respect to the products giving rise to such damages. Some jurisdictions do not allow the exclusion of or limitation on implied conditions, warranties or damages, thus some of the foregoing may not apply to Client.

3. Intellectual Property Rights. Hardware and Software are proprietary to Destinator Technologies or its suppliers and are subject to copyright and other intellectual property laws. Client's only rights with respect to any Destinator Technologies software included with the Products shall be provided, under the terms of Destinator Technologies' software licence. The title to all Destinator Technologies Software remains with Destinator Technologies. Client agrees that Destinator Technologies retains ownership of all rights, title and interest in all intellectual property, works of authorship, trade secrets and the like in all aspects of the Product(s). Client and its affiliates and subcontractors agree not to reverse engineer any aspect of the Software and/or Products supplied under this agreement and further agree to pay assessed damages should such action take place.

4. Copyright and Copies. The Software (including any copy thereof) is owned by Destinator Technologies or its suppliers and is protected by United States, Canadian, European, Brazilian and Australian copyright and patent laws and international treaty provisions. The Software copy is licensed to you the client, not sold to you, and you (the client) are not an owner of any copy thereof. You may make one copy of the software for backup or archival purposes. You may not otherwise copy the software, except as authorised by applicable law, nor the written materials accompanying the Software. Destinator Technologies hereby reserves all rights not explicitly granted in this license agreement.

Copyright © 2008, Destinator Technologies

Downloaded from www.vandenborre.be

Contents

1. Getting Started 2

Configuration Wizard 2
Demo 2
Main Map 3
Map Views 4
Route Overview 5
Cancel Route 5

2. Select Location and Generate Route 6

Go to an Address 6
Points of Interest (POI) 10
QuickNav 12
Recent Locations 12
Favourite Locations 13

3. Additional Destinator Features 16

Driving Directions 16
Multiple Stops 17
Avoid Roads 18
Detour 20
Map Browsing 20
Pedestrian Mode 21
Map Selection 21

4. Destinator Configurations 23

Settings Menus 23
Prompts 23
Language settings 24
Look & Feel Settings 24
Units of Measure 25
Time Settings 25
Map Settings 26
Start Demo 27
About 27
Help 27

5. Destinator PC Portal 28

Destinator PC Portal Installation 28
PC System Requirements 28
Destinator PC Portal Wizard 29
Destinator PC Portal Main Screen 30
Map Installation 32
Google™ Earth Placemarks 33
Favourite Locations - Import 35
Favourite Locations - Export 36
General Warning Messages 36

Index 38

Downloaded from www.vandenborre.be

1. Getting Started

Welcome to the world of mobile navigation! Simple operation, clear maps in 2D or 3D mode as well as numerous innovative features and functions have made **Destinator** the essential guide for every traveller - whether in the car, on foot or by bike.

Configuration Wizard

This wizard, which automatically starts the first time you use **Destinator**, lets you easily configure the system settings by providing a step-by-step setup process. You can also configure these system settings by going to these system options from the **Settings** menu.

- **Language Settings** - Set text and voice language preferences.
- **End User Licence Agreement (EULA)** - Please review the licence information and tap the **Agree** button. The **EULA** screen appears each time you use a new map.
- **Time settings** - Set to display time settings.
- **Units of Measure** - Specify the system measurement units.
- **Prompts** - Configure the general navigation prompts and notifications and how these are displayed (for example, Text or Symbol).
- **QuickNav Settings** - Specify an Address or Point of Interest (POI) that **Destinator** navigates to when you tap the **QuickNav** button on the **Main Map** screen.
- **Driver Warning** - When you start **Destinator**, the **Driver Warning** screen appears. Please take a moment to review the information provided before selecting the "Do not display this warning again" checkbox to skip this message in the future.


Warning
It is your responsibility to use Destinator in a manner that does not diminish your driving ability. You should not operate Destinator while the vehicle is in motion. You are required to comply with all state laws regulating the use of this device and to assume total responsibility and risk for its use.
Do not display this warning again.
Disagree
OK

Figure 1 - Map Warning Screen

Demo

The **Start Demo** button lets **Destinator** display a simulated route. Many of the **Destinator** navigation features are disabled when the demo is running. You can end the demo by tapping the **Stop Demo** button from the **Settings** menu.

Downloaded from www.vandenborre.be

Main Map

You can use the icons displayed on this screen to plan and view your route.

Figure 2 - Map Screen

Main Map Icons

1, 6		Zoom in or out of the map to view a larger less detailed area or a smaller area in greater detail
2		Tap the compass to change the map view display as follows: 2D map view with the forward direction at the top. 3D map view with the forward direction at the top. 2D map view with North at the top.
3		Tap this icon to adjust or mute the volume.
4		When you have calculated a route, the Directions bar displays information about your next turn. Tap this bar for a complete list of turn-by-turn directions.
5		The GPS bar is a toggle button that displays the remaining travel distance and travel time, estimated time of arrival, street name and address number, speed and altitude.
7		The red GPS receiver means that a reliable GPS signal is not yet located. The green GPS receiver means that a reliable GPS signal is located and that you are ready to navigate.
8		These icons display your power source. The battery appears as green, yellow or red depending on the strength of the battery charge.
9		Tap this icon to set your **QuickNav** location. When set, you can tap this button to automatically calculate a route to this location.
10		Tap this icon to display the **Main Menu**.

Downloaded from www.vandenborre.be

Location Icons

	Current location in Vehicle Mode or Pedestrian Mode.
	Last known location when GPS signal is unreliable.
	Generated route

Location Point on Main Map

You can drag the map to a specific point and tap the desired location directly on the **Main Map** screen in both 2D and 3D map view. This feature is useful when you want to navigate to a specific point on the map, rather than by the street address. When you tap on the map, the pop-up menu appears with the following options:



Figure 3 - Point on the Map Options

Go There - Navigate to the selected point on the map.

Save - Save a point on the map as a favourite destination for future use.

Start Here - Designate the selected point as the starting point instead of your current location.

Map Views

You can choose to see a two-dimensional or three-dimensional map adjusted specifically for daylight or night time conditions.

From the **Options** menu, tap the **Day/Night Mode** toggle button to view the map for day or night time driving and the **2D/3D Mode** toggle button to display the map view in 2-dimensional or 3-dimensional views for day or night driving.

Downloaded from www.vandenborre.be

Route Overview

- From the **Route** menu, tap the **Route Overview** button.

An overview of your complete route, the total driving distance to your destination, the estimated travel time and the complete destination address, are displayed on the Map Manager screen.

Cancel Route

- From the **Route** menu, tap the **Cancel Route** button.

The current navigation stops and **Destinator** clears the route. You can only cancel a route after a destination has been set.

Downloaded fr
www.vandenborre.be

2. Select Location and Generate Route

Go to an Address



From the **Go To** menu, tap the **Address** button. The **Address Search Mode** screen appears, allowing you to choose how you want to enter address information. For example, if you select **City First**, the first address screen lets you select from a list of cities, the second screen a list of streets, and the third screen lets you enter an address number.

Select from the following address entry options:

- Town/City First - *Town/City > Street > Address Number*
- In All Cities - *Street > Town/City > Address Number* - You enter a street name without having to first select a town or city. This is useful when searching for an address in a metropolitan area where there are many cities and towns.
- Intersections- *Town/City> Street > Street 2*
- Postcode - *Postcode, Street, Address Number* - You can locate a street address by entering the post code, without entering a town name, which is useful when you have no information about the town.

Note: When the United Kingdom map is selected, the first address screen is always **Select County**.

Tap from one of the **Address Search Mode** options to display the first address screen.

Figure 4 - Selecting an Address

When entering an address, you can use the keyboard to enter the characters. The characters appear in the **Address** field. **Destinator** automatically searches the **Address** list for the first occurrence of the characters entered. After you have selected a town or city, **Destinator** displays the next address field, such as street and address number.

Instead of specifying a street, you have the option of selecting the **Town/City Centre**. If you don't know the address number, you can select the Street Midpoint.

Tap the **OK** button to move through the sequence of address screens.

Downloaded from www.vandenborre.be

Go to Another Country

From the **Address Search Mode** screen, you can tap **In Other Countries** to select another country that you can travel to by vehicle.

This feature is available only when you have the following maps installed:

- Map of the country where you are currently located.
- Map of the country where you want to travel.
- The map of the major roads for that continent that connect one map to another (for example, the major roads in Europe)

For example, if you are in Paris and you want to travel to Munich, select the map of Germany and designate Munich Town Centre as your destination. **Destinator** automatically displays the map of France when travelling on local roads in France, a map of Major Roads in Europe when travelling on a European motorway, and the map of Germany when travelling on local roads in Germany.

Destinator Screen Buttons

The following buttons appear on many of the navigation screens.



When you tap this button for a selected address, group or place, **Destinator** automatically opens the next screen in the sequence.



When you tap this button, **Destinator** returns you to the previous screen.



This button provides a list of command options available for the selected address or place.

Downloaded from www.vandenborre.be

Keyboard Command Keys

The following buttons are available to enhance your search process.

Figure 5 - Search and Keyboard Buttons

1	Lets you remove a character that you have entered.
2	Lets you scroll up or down the list of town/city or street names.
3	Lets you display different keyboards, including special characters (for example, Greek) and numbers. The operating system installed on the device must be able to support these characters. **Note: Destinator** lets you search for town/city and street names without having special characters, such as umlauts or accent marks, which are used in many European languages. For example, you can enter Munchen for München
4	Lets you extend the address list by hiding the keyboard.
5	Lets you hide or display the keyboard.

Navigate to an Address

Figure 6 - Show on Map

You can select from the following route types:

Quick - This option selects the route that takes the least amount of time. Quick is the default setting.

Short - This option selects the route that is shorter in distance. Note: The shorter route may not always be the quickest.

Go - When you tap the **Go** button, **Destinator** calculates the route to your selected destination.

Demo - Tap the icon to start navigating a simulated route.

Note: Route generation excludes any detours, stops or delays along the route.

Downloaded from www.vandenborre.be

Actions

Tap the **Actions** button to:

- **Set an Address as the point of origin** - Tap the **Start Here** button to designate the selected address as the route origin.
- **Show on map** - Tap to see the selected address on the map.
- **Save** - Tap to add an address to your list of favourite locations. For more information about favourites, see Favourite Locations on page 13.
- **Information -** Tap to display additional address information and phone number.

Downloaded from www.vandenborre.be

Points of Interest (POI)

The Points of Interest (POI) list is a collection of hundreds of interesting or useful places organised by easy-to-find categories. For example, you can use **Destinator** to guide you to a shopping centre, hotel, restaurant or petrol station.

Many categories have subcategories to provide for an even greater list of choices. For example, petrol station, may have many subcategories each representing a particular brand name. The same is also true for hotels. Restaurants have subcategories that represent different types of food, such as Indian, Italian and French.

Search for a Location Near You

You can determine the area where you want to search for a specific place, such as a petrol station, hotel or restaurant. **My Current Location** is automatically selected.



Tap to search near your current location.

Tap to search near your specified destination. If a destination has not been selected and a route generated (by tapping the **Go** button), this button is disabled.



Tap to search for a POI in another location. This button opens the **Address Search Mode** screen, which is described in Go to an Address on page 6.

Search for a POI Name

Tap this button to display the **Search POI** keyboard screen, where you can search by entering text in the **POI Name** field. The Smart Search System automatically displays the POI names that match the characters entered. **Destinator** automatically displays the POI entries and the distance each entry is from your current location.

For example, if I enter “Avis” and tap the **Search** button. Destinator displays all Avis entries in my selected location, as shown in the figure below.



Figure 7 - Search by POI Name

Downloaded from www.vandenborre.be

Search for a POI Category



Tap this button to display the most common POI categories.

Figure 8 - Most Common POI Categories

Tap **More** to display the **Point of Interest** screen, where you can search through the entire list of POI categories.

Show or Hide Symbol on Map

You can select or clear the ticks next to a **POI** entry to show or hide the **POI** symbol on the **Main Map** screen.



Figure 9 - Showing a POI Symbol on the Map

Actions

Tap the **Actions** button to:

- **Start Here** – Tap button to designate the selected address as the route origin.
- **Show on map** – Tap to see the selected address on the map.
- **Save** – Tap to add an address to your list of favourite locations.
- **Sort by ABC** - Tap the button to display the category entries in alphabetical order.
- **Information** – Tap to display additional address information and phone number (where available).

Downloaded from www.vandenborre.be

QuickNav

You can set a **QuickNav** destination so that every time you tap the icon on the **Main Map** screen, **Destinator** automatically calculates the route to this destination for you. When you tap the **QuickNav** button for the first time, you must select a predefined address or a POI category.



Figure 10 - Setting the Quick Nav Location

You can change the **QuickNav** settings by tapping the **QuickNav** button located on the **Settings** menu.

Recent Locations



From the **Go To** menu, tap this button to select an existing destination from a list of destinations that you have previously travelled to.



Figure 11 -Travelling to a Recent Location

Destinator automatically stores the last 64 destinations in memory. After 64 destinations have been saved, the older destination entries are erased.

Actions

Tap the **Actions** button to:

- **Set an Address as the point of origin** - Tap the **Start Here** button to designate the selected address as the route origin.
- **Save** - Tap to add an address to your list of favourite locations.
- **Delete an item** - Tap the **Actions** button. Tap the **Delete Item** button to delete an entry on the **Recent Locations** screen.
- **Clear the recent location list** - Tap the **Actions** button. Tap the **Clear List** button to clear all locations in the **Recent Locations** screen.
- **Information -** Tap to display additional address information and phone number.

Downloaded from www.vandenborre.be

Favourite Locations

A **Favourite** is a destination that you have stored for easy retrieval. Save favourite destinations to your **favourites groups** and later you can easily travel to these destinations.

Note: You can also add a favourite destination from the **Address**, **POI**, and **Recent Locations** screens.

Save a Favourite Location



From the **Actions** screen, tap this button. Select the group to which you want to add your favourite destination.



Figure 12 - Adding a Destination to Your Favourites

The **My Favourites** folder is the default folder where all favourites are stored if not assigned to a group. This folder cannot be deleted.

Going to a Favourite Location



From the **Go To** menu, tap this button to display the screen containing your favourite groups. Select a group, for example **Restaurants**. **Destinator** automatically displays a list of stored locations for the selected group.



Figure 13 - Going to a Favourite Destination

You can add or clear the tick next to a **Favourites** entry to show or hide the **Favourites** symbol on the **Main Map** screen.

Downloaded from www.vandenborre.be

Creating a Favourite Group



From the **Favourites** screen, tap this button to add, edit or delete groups. Enter a group name and select a group icon.



Figure 14 - Adding a Favourites Group

To add favourite destinations to your favourite groups, see Save a Favourite Location see "Save a Favourite Location" on page 13.

Setting an Alert for a Favourites Group

Alerts let you know that you are within a certain distance of an item in a **Favourites** group.



Figure 15 - Setting Your Favourite Alerts

Use the right and left scroll arrows to set the distances for the 1st and 2nd Alerts.

In the **Set Alert Distances** screen, you can disable an alert by setting the 1st Alert to **Off** or by clearing the checkbox next to the selected group.

Notes:

- **Favourite Alert** settings affect all **Favourites** groups.
- The 2nd Alert must be set to sound at a closer distance than the 1st Alert.
- Alerts can be set for a group but not for individual locations. Of course, you can always create a group that has just one location.

Downloaded from www.vandenborre.be

Actions

Tap the **Actions** button to:

- **Set an address as the point of origin** - Tap the **Start Here** button to designate the selected address as the route origin.
- **Show on map** - Tap to see the selected address on the map.
- **Edit a favourite location** - Tap the **Actions** button. Tap the **Edit Favourite Location** button to change the name, comment or group location for the selected location.
- **Delete a favourite location** - Tap the **Delete Favourite Location** button to remove the selected location.
- **Information** - Tap to display additional address information.

Downloaded fr
www.vandenborre.be

3. Additional Destinator Features

Driving Directions

From the **Route** menu, tap this button to display a complete turn-by-turn list of directions from your current location to the selected destination. **Destinator** continuously updates the Turn-by-Turn screen to display the most current instructions as you navigate the route.



Figure 16 - Turn-by-Turn Display

Note: The first turn is at the top of the list and the final turn is at the bottom, identified by a chequered flag.

The following options are available:

Route Tap to display your entire route on the **Main Map** screen, plus the travel distance and the **Estimated Travel Time Remaining** (ETR).

Turn Tap to display the next turn on the **Main Map** screen, including the street name, the distance to the turn and the turn direction.

Avoid Tap to avoid the selected turn in the **Turn-by-Turn** list. **Destinator** recalculates the route automatically. Note that when you exclude a turn, the recalculated route may take longer.

Downloaded from www.vandenborre.be

Multiple Stops

From the **Extras** menu, tap this button to create a trip with multiple (up to 12) stops.



Figure 17 - Travelling to Multiple Stops in a Single Trip

When you tap the **Go** button, the route is calculated in stages, from the departure point to the first stop. When you reach the first stop, the route recalculates to the second stop and so on. If you select a stop in the middle of your list, **Destinator** will calculate your route to that stop and will recalculate to the next stop on the list and so on.

Creating a Group

Tap the **Actions** button and select **Add Group**. From the **Add Group** screen, enter the **group** name and tap **Save**. The **Actions** screen also lets you edit or delete a selected group.

Adding Stops

Select a group and tap **Next** to add locations. Tap **Actions** to add an **Address**, **POI**, **Favourites** or **Recent Locations**. The location appears on the **Multistop** screen. You can move the location up or down on the stops list, change the location name, enter a comment or designate a different group.



Figure 18 - Specifying a Stop

Organising Your Itinerary

There are two different ways to organise your itinerary, by manually rearranging your stops or by automatically optimising your route.

Tap the **Up** and **Down** buttons to move the selected stop up or down the list of stops.

Alternatively, you can automatically optimise your route for the most efficient travel experience. This feature is most useful when you are planning stops that are far apart and it is unclear how to order the stops to create the most efficient travel itinerary.

Tap the **Optimise Route** button. The list of stops is automatically rearranged to provide the most efficient travel route.

Downloaded from www.vandenborre.be

Actions

Tap the **Actions** button to:

- **Start Here** - Tap to designate the selected address as the route origin. You would use this option when calculating a route from a point other than your current location.
- **Add Stop** - Tap to add a location by specifying an address from recent locations, favourite locations or predefined POIs, such as fuel, food, or lodging.
- **Rename Stop** - Tap to change the stop information, such as name, comments or route group.
- **Delete Stop** - Tap to remove a selected stop.
- **Information** - This button displays the location's address information.

Avoid Roads

You can specify that certain roads be permanently excluded from your route calculations. Use this feature when you want to avoid congested roads, toll roads or unsafe streets.

From the **Route** menu, tap the **Avoid Roads** button. The **Avoid Roads** screen appears, displaying predefined road groups.



Figure 19 - Predefined Road Groups

Destinator provides the following predefined road groups:

- **Ferries** - The default value is to avoid
- **Gated Communities** - The default value is to allow
- **Motorways** - Roads that allow for high volume, maximum speed traffic movement between and through major metropolitan areas. The default value is to allow
- **My Roads to Avoid** - This is a default folder that lets you store roads to avoid. You can display the items in this folder and allow or avoid specific roads.

  The default value is to avoid

To allow or avoid a predefined road group:

- Select a predefined group and tap the **Allow / Avoid** toggle button. The next time you calculate a route, **Destinator** calculates a route based on your avoid or allow selections.

Note: predefined road groups are allowed or avoided as an entire group. You cannot allow or avoid individual toll roads, motorways or ferries.

Downloaded from www.vandenborre.be

Creating a Group



Tap this button and select **Add Group**. From the **Add Group** screen, enter the **group** name and tap **OK**



Figure 20 - Add a Road Group

The **Actions** screen also lets you edit or delete a selected group.

Adding a Road to Avoid

When you tap **My Roads to Avoid** or a road group, **Destinator** displays the group screen, which lets you designate roads to avoid. From this screen, you can use the **Allow** or **Avoid** buttons to include or exclude individual roads when calculating a route.



Figure 21 - Storing Road Locations

Tap **Actions** and then the **Add Road** button. Select the town/city and street. The road is displayed on the **Show on Map** screen. Tap the **Avoid** button.



Figure 22 - Adding a Road to Avoid

Downloaded from www.vandenborre.be

Actions

Tap the **Actions** button to:

- **Edit Road** - Tap to rename the road and/or select a different group. When you have made your changes, tap **Save**.
- **Delete Road** - Select a road and tap this button to remove the road from your group. **Destinator** no longer avoids the removed road.
- **Show on Map** - Tap to show the map with the displayed destination for you to review before creating a route.
- **Information** - Tap to display the location's address information.

Detour

From the **Route** menu, tap the **Detour** button. The **Detour** screen lets you instruct **Destinator** to create a detour to avoid a road event, such as an accident.



Figure 23 - Avoiding a Road Event by Performing a Detour

Select the **Detour** option that you want to generate a detour for the distance specified. For example, if you are travelling on a major motorway and you are alerted by the news that there is traffic for the next 2 miles, you can have **Destinator** calculate a detour that takes you off the motorway and then returns you to the motorway after a distance of 2 miles.

Map Browsing



You can browse the map without a **GPS** signal. From the **Options** menu, tap the **Free Map Browsing** button to disconnect from the GPS receiver.

Figure 24 - Explore the Map

Downloaded from www.vandenborre.be

The icon identifies your current position. You can use the arrow cursor to move the map. When you have located the street destination, you can tap that point on the map. A pop-up menu appears. Tap **Go There** to navigate to the selected point.

You can reconnect to GPS, by going to the **Options** menu and tapping the **GPS Navigation** button.

Pedestrian Mode

Pedestrian Mode lets you travel as a pedestrian, generating a route up to ten kilometres, which is not limited by vehicle constraints, such as one way streets. When creating a pedestrian route, **Destinator** avoids motorways or other roads where pedestrians would not travel. **Voice prompts** are deactivated in this mode.

From the **Options** menu, tap the **Pedestrian** button. You can switch back to **Vehicle Mode** by tapping the **Vehicle Mode** button.



Figure 25 - Pedestrian Mode

Note: When **Pedestrian Mode is selected**, the **Turn-by-Turn**, **Route Summary**, **Avoid Roads** and **Multistop Planner** features are disabled.

Map Selection



From the **Options** menu, tap the **Select Map** button to change the selected map to another map saved on your SD memory card.



Figure 26 - Select a Map

Downloaded from www.vandenborre.be

Destinator immediately implements the selected map for all navigation features. If you are using a map for the first time, an **End-User Licence Agreement** (**EULA**) screen appears. Read it and then select the **Agree** checkbox to continue working with **Destinator**.

EULA
END USER LICENSE AGREEMENT
PLEASE READ THIS END USER LICENSE AGREEMENT CAREFULLY
BEFORE USING THE NAVTEQ DATABASE
NOTICE TO THE USER
THIS IS A LICENSE AGREEMENT - AND NOT AN AGREEMENT FOR SALE – BETWEEN YOU AND NAVTEQ B.V. FOR YOUR COPY OF THE NAVTEQ
I Agree
Back
OK

Figure 27 - Map's End-User Licence Agreement

You can also choose from the following **Select Map** commands:

- **Refresh** - Tap to refresh the screen when a new memory card is inserted into the device.
- **Delete** - Tap to permanently remove a selected map. **Note**: You cannot delete the map you are currently using.

Downloaded fr
www.vandenborre.be

4. Destinator Configurations

Settings Menus

From the **Options** menu, tap the **Settings** button to configure **Destinator** system settings and utilise travel playback and demonstration features.

Prompts



From the **Settings** menu, tap the **Prompts** button to select the types of voice and road name and number notifications that you would like to use while navigating.

Road Prompts

Speed Warning Warns you when your car exceeds the speed limit. This prompt is not active by default.

Route Recalculation Notifies you when **Destinator** recalculates your route. For example, when you miss a turn. This prompt is not active by default.

Unreliable GPS Signal Warns that the GPS signal is too low and unreliable for navigation. This prompt is automatically active by default.

GPS not found Alerts you if the GPS signal is lost or if the power source has been removed from the GPS receiver.

GPS Signal

From the **Settings** menu, tap the **GPS Signal** button to display GPS information and to configure the GPS connection settings.

Destinator receives data from a built-in GPS receiver or an external GPS receiver, connected to your navigation device through Bluetooth® Wireless Technology, to pinpoint your location. Your vehicle's location and position are constantly updated unless you are working in the **Free Browse Map** mode or you tap the **GPS Off** button. The GPS receiver may take a few minutes to find its initial location. For best results, ensure that the GPS receiver has a clear view of the sky.

The **GPS Signal** screen displays the following information:

- **Longitude**
- **Latitude**
- **Speed**
- **Altitude**
- **Number of Satellites**

If you are working in the **Free Browse Map** mode, **Destinator** automatically disconnects from the GPS receiver.

Downloaded from www.vandenborre.be

Language settings

From the **Settings** menu, tap the **Language** button to display the **Language Settings** screen.

Figure 28 - Language Settings

You can select from:

- Display Language - Address and map information, and screen and menu labels

Look & Feel Settings



From the **Settings** menu, tap the **Look & Feel** button to select from a list of preinstalled skins. A skin determines the visual effects such as colours and icons displayed.

- **Prefer QWERTY Keyboard** - When this option is selected, the navigation keyboard is displayed as a computer keyboard (QWERTY style) on the screens.
- **Auto Day-Night Adjustment** - When this option is selected, **Destinator** automatically switches between day and night view according to the GPS time and date information provided. If this option is selected, but you manually switch the day/night view, it will remain in the mode you selected until the next time **Destinator** automatically switches the day/night view.

Downloaded from www.vandenborre.be

Units of Measure

From the **Settings** menu, tap this button to specify the measurement system you would like to use.

You can select:

- Miles, Yards
- Miles, 10th of a Mile
- Kilometres, Metres

Time Settings



From the **Settings** menu, tap this button to display time settings.

Figure 29 - Time Zone

You can select the **Adjust to Daylight Savings** checkbox to automatically adjust for daylight savings.

Downloaded from www.vandenborre.be

Map Settings

From the **Settings** menu, tap the **Map Settings** button to select from the map interface options listed below.

You can choose the following options for the main map:

Rotate Map to Driving Direction	Orients the map so that the direction you are travelling in is always at the top of the screen.
Larger Labels	Increases the size of street names to make the map easier to read.
Allow Screen Tap	Displays the navigation popup menu when tapping on a map location.
Automatic Map Zoom	When selected, the zoom is speed dependent. The map zooms out at higher speeds, displaying a larger map area, and zooms in at slower speeds, displaying a smaller map area.
Manoeuvre Diagram	Displays a large image that indicates your next manoeuvre, such as left turn or right exit.
Display upcoming street name	Displays the next street name.
Allow Zoom Control	Displays zoom in and zoom out buttons.
Display Compass	Displays the compass, which lets you change the map view display: • 2D map view with the forward direction at the top. • 3D map view with the forward direction at the top. • 2D map view with North at the top.
Display QuickNav Button	Displays the **QuickNav** button, which you tap to navigate to a pre-selected location
Display Volume Control	Displays the **Volume Control** bar.
Display GPS Status	Displays whether a reliable GPS signal has been located.
Display Power Indicator	Displays if your device is plugged in or running on battery power.
Display Information Bar	Displays estimated time of arrival.
Display Menu Button	Displays the **Menu** button, which opens the **Main menu**.

Downloaded from www.vandenborre.be

Start Demo

From the **Settings** menu, tap this button to display a simulated route. Many of the **Destinator** navigation features are disabled when the Demo is running. You can end the Demo by tapping the **Stop Demo** button.

About

From the **Settings** menu, tap this button to display version and copyright information.

Help



From the **Settings** menu, tap this button to display technical support information.

Downloaded fr
www.vandenborre.be

5. Destinator PC Portal

Destinator PC Portal Installation

To install the Destinator PC Portal:

1. Insert the **Destinator CD** into the PC's CD drive. The **Destinator PC Portal Installation** wizard prompts you to select the language used for the installation process. When you have selected a language, click **OK**.
2. Read the **Welcome** message and click **Next**.
3. From the **Select Directory** screen, either accept the recommended default directory or browse to a different directory to install the **Destinator PC Portal**. Click **Next**.
4. If you want to change the language selection or the directory location before installing, click **Back** and change the language selection. When you are ready to install the **Destinator PC Portal**, click **Next**. The **Installation Status** box displays the progress of the installation process.
5. When the installation is complete, click the **Finish** button. The **Select Language** dialogue box appears.
6. From the **Select Language** dialogue box, you can select the display language for the **Destinator PC Portal**. Select the **Launch PC Portal** checkbox for **Destinator PC Portal** to start immediately. Alternatively, you can start the **Destinator PC Portal** from the Microsoft® Windows® Programs menu.

Note: You can uninstall the **Destinator PC Portal** by opening the **Microsoft® Windows Programs** menu, selecting *Destinator>Uninstall Destinator PC Portal*.

PC System Requirements

Please review the following system requirements before installing **Destinator PC Portal**:

- CPU: AMD/Intel® Processor 300 MHz or faster
- Operating system: Windows® 2000/XP/Vista
- Memory: 128 MB RAM (minimum)
- Hard drive free space: 500 MB (minimum)
- CD-ROM: 4x drive or higher
- ActiveSync Version 3.8 to 4.2 supported under Windows 2000 and XP
- USB Version 1.1 or 2.0 connection

Downloaded from www.vandenborre.be

Destinator PC Portal Wizard

Figure 30 -Destinator PC Portal Wizard Options

The first time you start the **Destinator PC Portal**, the PC Portal Wizard automatically starts, letting you install **Destinator** software, supported languages voice guidance options and maps. For a complete description of the **Destinator PC Portal**, see Destinator PC Portal Main Screen on page 30.

To open the Destinator PC Portal Wizard:

1. Click the **Microsoft® Windows Start** button.
2. Click *Programs* > *Destinator* > *Destinator PC* Portal. The **Destinator PC Portal** will start.
3. If this is your first time using **Destinator PC Portal**, the **Destinator PC Portal Wizard** automatically starts and displays the **Welcome** screen.
4. Make sure that your device is connected by USB cable to a port on your PC. You will see Connected on the **Destinator PC Portal** screen.
5. Click the buttons to move to the previous or next screen.
6. Select software components, languages and voice to install to your device.

Notes:

- If you want to start the wizard, click  from the **Destinator PC Portal Main** menu.
- If you want to stop the wizard, click This will open the **Destinator PC Portal Main** screen.
- If after you have adjusted the components, software and voice options, you want to return to the original selections, click .

Downloaded from www.vandenborre.be

Destinator PC Portal Main Screen



Figure 31 - Destinator PC Portal Main Screen

Destinator PC Portal Options

Install Software

Click Install Software and select from the following components to install to your device:

- **Destinator** - GPS navigation software
- **TMC** - Real time traffic information channel used by **Destinator**.
- **Slide Player** - A tutorial that displays **Destinator** features.

To install Destinator components:

1. From the **Install Software** screen, select from the list of components, as described above.
2. Click the **Install** button.
3. **Destinator PC Portal** installs the selected components to the device's main memory.

Manage Maps

Click **Manage Maps** to install or remove a map. For more information, see Map Installation on page 32.

Install Languages

Click **Install Languages** to install a language on your device.

To install languages:

1. From the **Install Languages** screen, select the languages to be installed on the device.
2. Click the **Install** button.
3. **Destinator PC Portal** installs the selected languages to the device's main memory.

Downloaded from www.vandenborre.be

Import Google™ Earth Placemarks

Click to import favourite locations designated as **Google™ Earth** Placemarks from your PC to the selected **Favourites** group on the device. For more information, see Google see "Google™ Earth Placemarks" on page 33™ Earth Placemarks see "Google™ Earth Placemarks" on page 33.

Import Favourites

Click to import favourite locations from your PC to the selected **Favourites** group on the device. For more information, see Favourite Locations see "Favourite Locations - Import" on page 35.

Export Favourites

Click to export favourite locations from your device to a selected location on your PC. For more information, see Favourite Locations.

Backup Destinator Data

Click the **Backup/Restore** button to backup the following **Destinator** items:

- **Favourites** - All locations that are displayed in **Destinator's Favourites** screens.
- **Multistops** - All locations that appear in **Destinator's** Multistops screens.
- **My Destinator** - Setting configurations, such as map views (2D/3D and Day/Night), prompts, units of measurement, as well as map and route setting preferences.

When you select **Backup**, **Destinator PC Portal** makes a copy and stores the information to your computer.

To backup Destinator data to your PC:

1. From the **Backup/Restore** screen, select **Backup**.
2. Select the **Destinator** items that you want to make a copy of and save to your computer.
3. Click the **Backup** button.
4. **Destinator PC Portal** saves the selected **Destinator** items to your computer.

Restore Destinator Data

Click the **Backup/Restore** button to restore **Favourites**, **Multistops** and **My Destinator** data to a navigation device. When you select **Restore, Destinator PC Portal** recovers the backup information stored on your computer.

To restore stored Destinator data to a navigation device:

1. From the **Backup/Restore** screen, select **Restore**.
2. Select the **Destinator** items that you want to restore.
3. Click the **Restore** button.
4. **Destinator PC Portal** restores the selected **Destinator** items.

Select Language

Click the **Select Language** button to show a list of languages available for viewing the **Destinator PC Portal**.

Select Device

Click the **Select Device** button to select from up to four connected devices. The **Select Device** screen lets you quickly install, import or export, backup or restore **Destinator** components and data for multiple devices.

Downloaded from www.vandenborre.be

Map Installation



Figure 32 - Installing a Map on the Device

After you have installed **Destinator** on your navigation device, you must install at least one map.

To install a map:

1. From the **Maps** pane, select a map.
2. From the **Memory Status** pane select a **Target** option, such as **Storage Card**, **Main Memory** or **Removable Disk**.
3. When you select a **Target** option, the **Destinator** PC Portal displays the following information:

   Required - The amount of free space necessary to install the map on the selected Target option.

   Available - The amount of free space available for the selected Target option.

Note: If the free space required is equal to or greater than the free space available, **Destinator PC Portal** will not install the selected map.

4. Click the **OK** button.
5. The selected map is installed and displayed in the Device Maps pane.

Notes:

- Click the Refresh Target button to update the target options.
- Click the Restore Defaults button to display the original map options.

Removing Maps

You can remove a map by selecting a map in the **Device Maps** pane and clicking the **Add/Remove** button.

Downloaded from www.vandenborre.be

Google™ Earth Placemarks

Import Placemarks lets you import **Google™ Earth** Placemarks into the device, which are displayed in **Destinator** under **Favourites**. **Google™ Earth** Placemarks are locations that you have designated on **Google™ Earth** as saved locations.

From a Web browser, go to http://earth.google.com/download-earth.html and download the free version of **Google™ Earth** and install as described in the **Google™ Earth** instructions.

To set Google™ Earth Placemarks:

1. From the **Microsoft© Windows Programs** list, click

to start the program.
2. On the globe, locate the country and then zoom in to display towns, streets and buildings.



Figure 33 - Enter the Activation Number

3. You can use the **Layer** pane to display street names, tourist information and more.
4. From the toolbar, click for the **Placemark** icon to appear. Drag the **Placemark** icon to the place you want to mark.
5. The **Placemark** dialogue box appears. You must enter a placemark name. You can also add other descriptive information. When done, click **OK**.
6. Select the **Placemark** icon and right-click to display a context-sensitive menu. In this menu, click **Save As**.
7. The **Save As** dialogue box appears. Browse to the folder where you want to store the placemark file and save the file as .kml.

Importing Google™ Earth Placemarks into your navigation device:

1. From the **Destinator PC Portal Main Menu**, click

to open the **Import Placemarks** screen.

Downloaded from manuals.plenborre.be



Figure 34 - Import Placemark Screen

2. Click the **Load Placemarks** button to display the placemark .kml files and select a file. The placemark appears in the **Loaded Placemarks** box. Select the checkbox to import the corresponding placemark to the device.
3. Select the group name for the selected placemarks. The default group name is **Favourite Placemarks**.
4. When you are ready to import the placemark files, click **Import**. These files are displayed in the selected group name under **Favourites** in **Destinator**.

Downloaded from www.vandenborre.be

Favourite Locations - Import

Import Favourites lets you import content created externally as a new **Favourites** category.

You can download a category of favourite destinations from your PC to your device. Destination data must be contained in a comma-separated values (.csv) file. You can import favourites into your device by following the procedure as displayed on the **Import Favourites** screen.


This feature lets you import your favorite destinations into Destinator.
1. Please select the file in CSV format:
Y:\V6.1\Generic V6.1\Stuff\spec\SPEEDCAMS.csv
...
2. Change the group name (optional):
SPEEDCAMS
3. Click OK to import the selected destinations to Destinator. A new group will be added to My Favorites.

Figure 35 - Importing Favourite Locations to Destinator

To import a .csv file into the device:

1. Connect the device to the PC with a USB cord.
2. From the **Destinator PC Portal Main** menu, click the **Import Favourites** button.
3. From the **Import Favourites** screen, click the ... button to browse for the .csv files stored on your PC.
4. Select a .csv file and click the **Import** button. A message appears letting you know that the category has been successfully exported from the device.

Note: From the **Import Favourites** screen, you can rename the category when importing the .csv file into your device.

The .csv file contains the following fields:

Name	Comment	Longitude	Latitude	Postcode	Town/City	Street	Address Number
Camera 1	Active	54.2345	23.345	34423	Munich	Hunche	7
McDonalds	+4954467892	34.234	12.456	45678	Berlin	Mark	23
Mikes	+4978343899	22.567	34.234	23412	London	Victoria	234

Notes:

- The name, longitude and latitude fields are mandatory.
- The longitude and latitude are numerical values. All other fields contain string values.
- Even if the .csv file does not contain all values, the separating commas must still be included.
- The .csv file contains the values in a table as a series of ASCII text lines, organised so that each column value is separated by a comma from the next column's value and each row starts a new line.
- If a string contains a comma, the entire string must be enclosed in (( )) (double parentheses).

Downloaded from www.vandenborre.be

Favourite Locations - Export

You can export a list of favourite locations from a navigation device to your PC. The list is stored on your PC in a .csv file. Exporting favourites is achieved by following the procedure displayed on the **Export Favourites** screen.

This feature lets you export your favorite destinations to the PC.
1. Please select available category:
...
2. Change the category name (optional):
SPEEDCAMS
3. Click OK to export the selected category to PC. A new CSV file will be created on your PC.

Figure 36 - Exporting favourite locations

To export a .dat file from the device:

1. Connect the device to the PC with a USB cord.
2. From the **Destinator PC Portal Main** menu, click the **Export Favourites** button.
3. From the **Export Favourites** screen, click the ... button to display the favourites categories stored on the device.
4. Select a category and click the **Export** button. A message appears letting you know that the category has been successfully exported from the device.

Note: From the **Export Favourites** screen, you can rename the category when exporting your .dat file.

General Warning Messages

The following warning messages may appear when you're working with **Destinator PC Portal**.

Lost connection transfer	If at any point during the installation or data transfer, the connection to the device is lost, the following message is displayed: "Connection to the device has been lost. Please check your connection."
Uninstalling Destinator Console	When a version of **Destinator Console** (versions prior to the **Destinator PC Portal**) is located on your computer, the following message is displayed: "A previous version of **Destinator Console** was found. Do you wish to uninstall?" It is recommended that the previous **Destinator Console** be uninstalled before installing **Destinator PC Portal**.

Downloaded from www.vandenborre.be

Uninstalling Destinator PC Portal	When an earlier version of **Destinator PC Portal** is located on your computer, the following message is displayed: "A previous version of **Destinator PC Portal** was found. Do you wish to uninstall? " It is recommended that a previous version of **Destinator PC Portal** be uninstalled before installing the current version.
Updates to Destinator PC Portal	If there are updates in **My Destinator**, you are prompted to download them in the following message: "There are updates to **Destinator PC Portal**, do you wish to download and install them?"
Previous maps	If maps from a previous **Destinator** version are located on your computer, the following message is displayed: "Existing map data found. Do you want to keep it? " Clicking **Yes** lets you install maps from previous **Destinator Console** or **Destinator PC Portal** versions.
Remove maps	The following message appears when you have selected an installed map and clicked the **Actions** button: "Selected maps will be removed from your device. Are you sure you wish to continue?"
Data Transfer	If you close the **Destinator PC Portal** while install **Destinator** software or a map, importing or exporting a Favourite location, or backing up **Destinator** data, the following message appears: "If you close the **Destinator PC Portal** now, the [Process] will not be completed. Are you sure you wish to close?"
Backup Data	If stored **Destinator** data is located on your computer, the following message appears: "**Destinator Backup** data found. Do you want to keep it?" It is recommended that backup data be kept."

Index

A

About • 27
Actions • 9, 12, 15
Add to My Favourites • 14
Adding a Road to Avoid • 19
Adding Stops • 17
Additional Destinator Features • 16
Alerts for a Favourite Group • 14
Avoid Roads • 18

C

Cancel Route • 5
Configuration Wizard • 2
Creating Group • 19

D

Demo • 2, 27
Destinator Configurations • 23
Destinator PC Portal Installation • 28
Destinator PC Portal Main Screen • 30
Destinator PC Portal Wizard • 29
Destinator Screen Buttons • 7
Detour • 20
Driving Directions • 16

E

Exporting Favourite Locations • 36

F

Favourite Locations • 13

G

Go to an Address • 6
Go to Another Country • 7
Going to a Favourite Destination • 13
Groups • 14

H

Help • 27

I

Import Favourite Location • 30
Importing Favourite Location • 35
Installing Maps • 30
Introduction • 2

L

Language settings • 24
Location Icons • 4
Location Point on Main Map • 4
Look & Feel Settings • 24

M

Main Map • 3
Main Map Icons • 3
Map Browsing • 20
Map Installation • 32
Map Selection • 21
Map Settings • 26
Map Views • 4
Multiple Stops • 17

N

Navigate to an Address • 8

O

Organising Your Itinerary • 17

P

Pedestrian Mode • 21
POI category • 11
POI Name • 10
Points of Interest (POI) • 10
Prompts • 23

Q

QuickNav • 12

R

Recent Locations • 12
Removing Maps • 32
Road Prompts • 23
Route Overview • 5

S

Save a Favourite Location • 13
Search for a Location Near You • 10
Search for a POI Category • 11
Search for a POI Name • 10
Select Location and Generate Route • 6
Show or Hide Symbol on Map • 11
Start Demo • 27

U

Units of Measure • 25

Downloaded from www.vandenborre.be